



## **INSTALLATION OF COVENTRY SERIES DECORATIVE GLASS TRIMS:**

- 1) Remove the decorative glass from trim (if installed) by grasping edge of glass, and rotating counterclockwise. Pull glass straight up from trim, and set aside.
- 2) Loosen the four 6-32 screws of the fixture's support brackets a few turns. Install reflector trim by engaging the 4 screws at the top, and rotating clockwise. Tighten all screws firmly. If fixture is fluorescent, install lamp(s) per standard instructions included with unit.
- 3) Before attaching decorative glass lens to reflector, examine the 3 slots/slides located at the top edge of the glass. These are meant to align with the corresponding springs near the lower edge of the reflector. Take note of the slight bumps that are 1" to the left of the slots. These are safety stops, and must be passed by the springs during glass installation.
- 4) Take glass to ceiling, and engage the 3 reflector springs into the 3 mating slots in the glass. Press fully up against reflector flange, and rotate clockwise. Depending on your glass type, you should be rotating the glass from at least 1-1/2" to 2-1/2". It is important that you pass the 1" area described in (3) above.
- 5) With glass cleaner, wipe any smudges or oil from your hands from glass surface.
- 6) Energize and test fixture as per standard instructions.

090-4\_6DEC GLS 03/01

*PATHWAY LIGHTING PRODUCTS, INC., 175-5 Elm St. P.O. Box 591, Old Saybrook, CT 06475*  
*PHONE (860) 388-6881 / (800) 342-0592 Fax (860) 388-5766 / (800) 207 0090*  
*E-mail: [sales@pathwaylighting.com](mailto:sales@pathwaylighting.com) [www.pathwaylighting.com](http://www.pathwaylighting.com)*